

Pump Repair Kit Chart

Pump Model	Valves	Piston	Water	Oil	Support Ring	O-Ring	Piston Guides	Unloader	Chemical Injector	Special Parts		
										Viton Water Seals	Hot Water	EZ Start
RK, RKA Ø 18 - E	2864	2546	1857	1855	1829					2809	2819	
RK, RKA Ø 18 - N	2864	2546	1857	1855	1829					2809	2819	
RK, RKA Ø 20 - E	2864	2547	1887	1855	1815					2810	2820	
RK, RKA Ø 20 - N	2864	2547	1887	1855	1815					2810	2820	
RK, RKA Ø 22 - E	2864	2759	1888	1855	1816					2811		
RK, RKA Ø 22 - N	2864	2759	1888	1855	1816					2811		
RKA-SS Ø 18 - E	2514	2552	2516	2529	1829							
RKA-SS Ø 22 - E	2514	2526	2527	2529	1816							
RK-SS, RKA-SS Ø 18 - N	2514	2552	2516	2528	1829							
RK-SS, RKA-SS Ø 22 - N	2514	2526	2527	2528	1816							
RKV - D	1828	2546	1857	1856	1829					2809	2819	
RMV - D 2 GPM	2233	2234	42122	2236		2237		42118				
RMV - D 2.5 GPM	42123	42161	2235	2236		42107		42118				
RMW - D 2 GPM	2233	2234	42122	2236		2237		42118				
RMW - D 2.5 GPM	42123	42161	2235	2236		42107		42118				
RSV - D w/handle on unloader	2186	2187	2189	2188		2190	2191	40128				
RSV - D w/o handle on unloader	2186	2187	2189	2188		2190	2191	2280				
RTF - N	42307	42308	42310	42309			42311					
RTP - N	42156	42157	42159	42158			42160					
SHP - N	2185	2872	2874	2873			42120					
SJV - D	2869	2513	2167	2797		2799		2824	42125			2594
SJW - D	2869	2513	2167	2797		2799		2824				
SXMA Ø 15 - E	2125	2544	2741	2787	2740					2776		
SXMA Ø 18 - E	2125	2545	2747	2787	2745					2777		
SXMV - D	2125	2544	2741	2787	2740					2776	2717	
SXW, SXWA - N	2871	2548	2874	2873			42120					
XM, XMA Ø 15 - N	1864	2544	2741	2786	2740					2776		
XM, XMA Ø 18 - N	1864	2545	2747	2786	2745					2777		
XMA 1-1/8 Ø 15 - E	1864	2544	2741	2787	2740					2776		
XMA 1-1/8 Ø 18 - E	1864	2545	2747	2787	2745					2777		
XMA 3/4 - N	1864	2544	2741	2786	2740					2776		
XMA 5/8 - E	1864	2544	2741	2787	2740					2776		
XMA-SS - N	2631	2645	2644	2787	2740							
XMV - D	1864	2544	2741	2787	2740					2776	2817	
XMV - E	1864	2544	2741	2787	2740					2776	2817	
XT, XTA Ø 15 - N	1864	2628	1866	1872						2029	2815	
XT, XTA Ø 18 - N	1864	2629	1874	1872						2030	2816	
XTA Ø 15 - E	1864	2628	1866	1860						2029	2815	
XTA Ø 18 - E	1864	2629	1874	1860						2030	2816	
XTV - D	1864	2628	1866	1860						2029	2815	
XTV - E	1864	2628	1866	1860						2029	2815	
XTV - N	1864	2628	1866	1872						2029	2815	
XW, XWA Ø 20 - N	2780	2542	2782	2781			2784			2778		
XW, XWA Ø 22 - N	2780	2543	2783	2781			2785			2779		
XWL-SS - N	2162	2163	2164	2781			2165					
XW-M, XWA-M - N	2780	2288	2278	2781			2279					
XWT, XWF, XWL, XWLA - N	2780	1849	1853	2781			2507			2036		